Technical Note: Custom NTP server configuration

137 Les Carr Fri, Aug 11, 2017 Fortigate UTM 3598

Products

FortiGate v5.0
FortiGate v5.2
FortiGate v5.4
FortiGate v5.6

Description

This article provides an example of the configuration of a custom NTP server via CLI.

Solution

A custom NTP server can be configured via CLI as follows:

```
config system ntp
set ntpsync enable
set type custom -----> Change type first
set syncinterval 1
config ntpserver
edit 1
set server "1.1.1.1" -----> NTP server IP
set ntpv3 disable
next
end
set source-ip 0.0.0.0
set server-mode disable
end
```

Further information can be found in the appropriate version of the "CLI Reference guide" in the Fortinet Document Library.

Online URL: https://kb2.ic.uk/article.php?id=137