

# Sangoma Handsets Default login

164 Jonathan Thu, Oct 5, 2017 [How to and FAQs](#) 9372

The default login details for a default Sangoma handset is;

Username: admin

Password: admin

This should be the default password for handsets out of the box or after a factory reset, please note that these handsets support zero touch and if purchased via us they will most likely upon first boot or reset just connect directly to your PBX and the password will change to your PBX systems password. This will be the password you have specified for handset admin and user access see steps below;

The screenshot displays the Sangoma Admin web interface. At the top, there is a navigation bar with tabs: 'talk', 'Modules', 'Basic Mode', 'Dashboard', and 'UCP'. Below this, a sidebar menu is visible on the left, and a main content area shows a grid of links categorized by 'Admin', 'Applications', 'Reports', and 'Settings'. In the 'Settings' category, 'EndPoint Manager' is highlighted with a red circle. Below the main content area, the 'EndPoint Manager' section is expanded, showing a description and a sidebar menu with 'Global Settings' highlighted by a red circle.

**Admin**

- Administrators
- Asterisk CLI
- Asterisk Modules
- Backup & Restore
- Blacklist
- Bria Cloud Solutions
- Bulk Handler
- CID Superfecta
- CallerID Lookup Sources
- Certificate Management

**Applications**

- REST API
- RMS Management
- Sound Languages
- System Admin
- System Recordings
- User Management
- XMPP
- XactViewV3 Admin
- Zulu
- Announcements

**Reports**

- Follow Me
- IVR
- Languages
- Misc Applications
- Misc Destinations
- Paging and Intercom
- Park and Announce
- Parking
- Queue Callback
- Queue Priorities
- Queues

**Settings**

- DAHDI Channel DIDs
- DAHDI Config
- Firewall
- Inbound Routes
- Outbound Call Limit
- Outbound Routes
- SIPSTATION
- Trunks
- Asterisk Info
- Asterisk Logfiles
- Weak Password Detection
- Advanced Settings
- Asterisk IAX Settings
- Asterisk Logfile Settings
- Asterisk Manager Users
- Asterisk REST Interface Users
- Asterisk SIP Settings
- CRM Settings
- EndPoint Manager**
- Pbx Configuration

**EndPoint Manager**

**About Endpoint Manager**

This module is used to automatically provision & configure Desk Phones, Wireless Phones, Door Phones, Overhead Paging Devices, Gateways, and Specialty devices from supported manufacturers.

For information and instructions on using Endpoint Manager, please see the Endpoint Manager Wiki .

To get started please choose an option in the Menu on the right.

**EndPoint**

- Global Settings**
- Extension Mapping

**Brands**

Then in the next screen add your desired passwords that your handsets will be set to;

Endpoint Manager

Global Settings

Internal Address ⓘ

External Address ⓘ

pbxXXXXXXXXX.ic-talk.co.uk

Ports ⓘ

HTTP Provisioning Port		Firewall Zone(s): Internal, Other
Secure HTTPS Provisioning Port		Firewall Zone(s): Internal, Other
RESTfull Apps Port		Firewall Zone(s): Internal
Secure RESTfull Apps Port		Firewall Zone(s): Internal

Authentication of HTTP or HTTPS provisioning requests from endpoints is currently **enabled**. Configuration of provisioning ports and credentials is done through Sysadmin Provisioning Management .

The username that is currently configured for HTTP and HTTPS provisioning is 'XXXXXXXXXX' and the password is 'XXXXXXXXXX' (without quotes).

Phone Admin Password ⓘ

123456

Phone User Password ⓘ

7890

ReSync Time ⓘ

86400

Seco

XML-API (RestAPI) Default Login ⓘ

Yes

No

Extension Mapping IP Addresses ⓘ

Yes

No

Extension Mapping Phone Status ⓘ

Yes

No

Value Correction ⓘ

Yes

No

Admin UCP for All ⓘ

Yes

No

Save Global

Online URL: <https://kb2.ic.uk/article.php?id=164>