


# Draytek firmware upgrade

207 Keira Tait Tue, May 22, 2018 [Draytek Routers](#) 1570

In order to update your Draytek's firmware, follow the below steps. Please note this guide is based off a Draytek 2860, and different models and firmwares may change.

First log onto your router, this can be done locally by going to 192.168.1.1 in a web browser, this is typically the Draytek routers IP address, however if changed you can find it by opening command prompt in Windows and in typing "ipconfig" your default gateway will likely be the Draytek, and you can get to this on a web browser by simply typing it in the address bar



Sign into the device with your username and password, typically admin and 1234 if default however this password may of been changed - if the Draytek was purchased by ourselves, we would of given a sheet of paper with the password on, however if you are still unaware, email support on [support@ic.co.uk](mailto:support@ic.co.uk) as we may have a record.

Once you are signed in, go to system maintenance > firmware upgrade

← → ↻ 192.168.1.1

**DrayTek** *Vigor2860 Series*

Auto Logout ▾ IP6

Dashboard  
Wizards  
Online Status

WAN  
LAN  
Hotspot Web Portal  
Routing  
NAT  
Firewall  
User Management  
Objects Setting  
CSM  
Bandwidth Management  
Applications  
VPN and Remote Access  
Certificate Management  
LTE  
Wireless LAN  
SSL VPN  
USB Application  
System Maintenance  
System Status  
TR-069  
Administrator Password  
User Password  
Login Page Greeting  
Configuration Backup  
SysLog / Mail Alert  
Time and Date  
SNMP  
Management  
Panel Control  
Self-Signed Certificate  
Reboot System  
**Firmware Upgrade**  
Modem Code Upgrade  
Activation  
Internal Service User List  
Dashboard Control  
Diagnostics

Central Management  
VPN  
AP  
Switch  
External Devices

Support Area  
Product Registration

All Rights Reserved.

System Maintenance >> Firmware Upgrade

**Firmware Version Status**

Current Firmware Version: 3.8.6\_STD

**Web Firmware Upgrade**

Select a firmware file.  
 No file chosen  
Click Upgrade to upload the file.

**TFTP Firmware Upgrade from LAN**


**Firmware Upgrade Procedures:**

1. Click "OK" to start the TFTP server.
2. Open the Firmware Upgrade Utility or other 3-party TFTP client software.
3. Check that the firmware filename is correct.
4. Click "Upgrade" on the Firmware Upgrade Utility to start the upgrade.
5. After the upgrade is complete, the TFTP server will automatically stop running.

Do you want to upgrade firmware?

**Note:**  
Upgrade using the ALL file will retain existing router configuration, whereas using the RST file will reset the configuration to factory defaults.

If your router is currently connected to the internet, you can select the check latest firmware option, and then select any of the firmwares as per the below



If you are not connected to the internet, you can select the Choose file option, this will allow you to upload the firmware from your local machine, Firmware for your Draytek can be found at - <https://www.draytek.com/en/download/firmware/>

### Web Firmware Upgrade

Select a firmware file.

No file chosen

Click Upgrade to upload the file.

Then select upgrade, your router will reboot but should come back in a few minutes, and if it asks - you want to select the "keep my current settings" option on reboot.

Online URL: <https://kb2.ic.uk/article.php?id=207>